


# SPOIL BOARD CONTENTS


## Spoil Boards for SD110 & SD120 Includes

Item Number	Quantity	Part Number	Part Name
1	8	208304	SD Spoil Board Slot
2	16	204267 (Kit)	1/4-20 Spotweld Nut
3	16	204267 (Kit)	1/4" Washer
4	16	204267 (Kit)	1/4-20 x 1/2 Phillips Pan

The SD110 Spoil Board Kit comes with the quantities listed here for full Aluminum T-Slot Bed coverage.




The SD120 Spoil Board Kit comes with double the quantities listed here for full Aluminum T-Slot Bed coverage.





## SPOIL BOARD Installation

**Assemble the slats by attaching the bolts, washers, and nuts as shown below. Do not overtighten the nut, it will need to be loose to slide into the Aluminum T-Slot Bed on the SHARK CNC.**



### X Assembly

**Once all slats are prepared as described, slide them into the Aluminum T-Slot Bed on the SHARK CNC in the orientation shown below**



### Y Assembly

**Position the slats flush with the front of the Aluminum T-Slot Bed on your SHARK CNC. On the SD120, position the second set of slats directly behind the first. Once all slats are positioned, tighten all bolts with a hand tool to secure the slats.**

